

Use to mount newel posts on finished floor surfaces

1. Place the bottom of the newel post against a flat surface. Using the metal bracket as a template, mark and predrill for the 1" screws using a 1/8" bit. Attach one (1) Bracket to each side of the newel post. **DO NOT EXTEND THE BRACKETS PAST THE BOTTOM OF THE NEWEL POST.**
2. Position the newel post with the mounted brackets on the floor, using the attached brackets as a template, mark the floor and predrill for the 2" screws using a 1/8" bit. Attach brackets to the floor. The angle of the brackets will force the post to the floor.
3. Attach the interlocking pre-mitered wood molding pieces to the brackets. Nail or glue the top edge of each piece of molding.

Tools Needed: 1/8" Twist Bit

