

Rail Fasteners

Fas-N-Fast™



Fas-n-Fast™

Newel Fastening System



- 1.** Using a 2" hole saw, drill a hole in the base center of your newel post. Use a router to bore out the hole to 13/16" deep. Drill your pilot holes and attach Fas-n-Fast™ using #10 (3-1/2") galvanized deck screws (not included).
- 2.** Mark center for the finished location of your newel. Secure Fas-n-Fast™ to floor joist using #10 (3-1/2") galvanized deck screws (not included). NOTE: If installing Fas-n-Fast™ on a starting step, place a block below the finished location of the newel and secure Fas-n-Fast™ to the block.
- 3.** Thread the newel post, rotating clockwise, to the installed bottom portion of your Fas-n-Fast™ hardware.

